



1700E Autoscrubber

PARTS LIST




1700E Autoscrubber

PARTS LIST




1700E Autoscrubber

PARTS LIST



1700E Autoscrubber

PARTS LIST



1700E Autoscrubber PARTS LIST

1.	PVT005	Lid (Solution Tank)	80	VPV087	Buffer
2.	PVT001	Solution Tank	81	VPA328CMG	Drive Motor
3.	PVT001A	Recovery Tank	81a	SK006	Screw 5/16
4	PVT035	Elbow Fitting	81b	VPV542	Nut 5/16
5	PVS060	Hose Quick Clamp	82	AAD041	Screw
6	PVS067	Solution Hose	83	VPA836	Rubber Grommet
7	PVS013	Solution Valve Assembly	84	VPA177	Base Plate
8	AAA537	6mm x 12mm Set Screw	85	VPA121	Wavy Washer
9	AAD039	Bolt	86	VPA570	Bearing
10	VPA284	Nut	87	VPA411	Gear
12	AAD038	1/4 x 1 1/2	88	VAA113	Cover Plate
14	COM019	Rubber Seal	89	VPA122	Washer
15	PVT100D	Bottom Plate (Vac Cover)	90	AAA564	Set Screw 1/4 x 3/4
16	PVS065	Spring	91	PVT045	Nut 5/16
17	PVT002	Vac Motor	92	PVT044	Cap Head Screw 5/16
18	COM019	Seal (Motor Support)	93	475480	Knob
19	VPA906	Spring Tensioner Trigger	94	PVS042	Gcrub Screw
20	AAA501	3/16 x 1 1/4 Screw C/S	95	PVT044	Cap Head Screw 5/16
21	VPV838	Trigger	96	VFB115	Woodruff Key
22	PVT100J	Exhaust Cover	97	PVT090	Height Adjustment Wedment
23	PVT100A	Handle Stem	98	PVS078	Drive Hub
24	VPA231	Tongue Assembly	99	PVS009	Height Adjustment Rod
25	AAF140	1/4 Nylon Nut	100	387116	Pilot Hub
26	VPA767	Fork	101	PVS087	Height Adjustment Bracket
27	VPA284	Handle Pin & Nut	102	PVS026	Cap/Head Screw 5/16 x 11/4
28	SLB038	3/16 Nylon Nut	103	AAA564	Set Screw 5/8 x 1/4
29	AAG236	Flat Washer	103a	GAS041	1/4 Spring Washer
30	PVT086	Support Bracket (Handle)	103b	AAG236	Washer
31	AAA604	Bolt (H/T 1/4 x 1) S/S	104	PVS092	Shaft
32	PVT027	Flat Washer	105a	PVS118L	Left Spring
33	SLB038	3/16 Nylon Nut	105b	PVS119R	Right Spring
34	PVS077	Water Release Hose	105c	PVS119L	Left Spring
35	PVT047	Plug PVT048 Sleeve	105d	PVS118R	Right Spring
36	VPV156	Ring	106	370711	Thumb Nut
37	PVS974	Terminal Block (5 Term)	107	VPA820	Spacer (Swivel Tongue & Squeegee)
38	PVS041	Wiring Box	108	PVS006	Swivel Squeegee
39	PVS096	Gland	109	PVS052	Skirt Assembly
40	AAM601	Terminal Block	110	VPV168	Mini Skirt (ref 109 Skirt Assy.)
41.	PVT200	Hose Clamp	111	VPV172	Retainer Skirt (ref 109 Skirt Assy.)
42	388019	Micro Switch (Activate Drive Motor)	112	VPV042	Pickup Ring (ref 109 Skirt Assy.)
43	VPA622	Half Clamp	113	PVS40B2	Brush
44	AAJ002	Star Washer	114	PVT009	Turn Buckle
45	AAA354	3mm Nut	115	SLB038	Nut Nylon
46	388019	Micro Switch (Activate Vac Motor)	115a	PVS039	S/S Nut 3/16
47	PVT008	Squeegee Lift Cable	116	VPA829	5/32 Roll Pin
48	AAA353	3mm x 25mm Screw	117	PVT038	Flat Washer
49.	PVT006	Lid (Recovery Tank)	118	PVT007	Wheels
50.	PVT015	Rubber Seal	119	SLB040	Flat washer
51	AAA354	6mm Nylon Nut	119a	GAS041	Spring Washer 1/4
52	PVT100K	Rod (Squeegee Lift Handle)	120	AAA564	Set Screw 5/8 x 1/4
53.	364527	Knob (Squeegee Lift Handle)	121	PVS006	Swivel Squeegee Tongue
54.	PVT100E	Squeegee Lift Handle	122	PVT011	Axle
55.	PVT100A	Backing Switch Plate	Ref pg4	382350	Squeegee Assembly
56.	PVT100G	Switch Plate	123	382352	Weldment
58	PVT100E	Washer (Activate Vac Motor)	124	105550	Channel
59	AAG385	Washer	125	105551	Retainer
60	PVS095	Hose Cuff	126	105533	Blade
61	PVS121	Extract Hose	127	393746	Weights
62	VVA019	No. 4 Clamp	128	370711	Thumb Nut
63	ZDR078	Indicator Light	129	387376	Roller Assy
65	PVT100F	Cover Plate	130	363855	Frame Roller
66	387670	Knob (Detergent Lift Handle)	131	ECG157	Lead Protector
67	PVT017	Rod Solution	132	PVT016	Plug & Lead
68	PVT028	3/16 x 5/8 Self Tap	133	300187	Belt Clip
69	VPV120	Clip (Hose Retainer)	134	PVS070A	Plastic Clamp
70a	VVA019	Cable Clamp No.4	135	VPV476	Lead
70b	BV8003	Ring	136	VPA459	Brass Barb 5/16
71	BV8003	Strain Relief	137	PVS059	Brass Reducer Bush
72	AAA564	Set Screw 1/4 x 3/4	138	PVS054	Washer 11/16 x 1 5/16
73	AAG236	Flat Washer	139	PVS013	Solution Valve Assy
74	VPA104	Oil Seal	140	PVS084	Solution Valve Retainer
75	VPA114	Bearing	141	PVT028	Screw
76	VPA116	Shaft	142	PVT018	Hinge
77	AAA501	3/16 x 1"	143	AAE232	Dom Nut
78	PVS424	Casting	144	AAK044	Pop Rivet
79	VPV239	Insert			

1700E/A23 VPA328CMG

- | | | |
|----|-----------|---------------------|
| 1 | VPV818CMG | Capacitor Box Cover |
| 2a | VPV804CMG | Start Capacitor |
| 2b | VPV798CMG | Run Capacitor |
| 3 | VPV817CMG | Capacitor Box Base |
| 4 | VPV807CMG | Manual Reset |
| 5 | VPV813CMG | Cowl |
| 6 | VPV812CMG | Cooling Fan |
| 6a | VPV819CMG | Clip on cooling fan |
| 7 | VPV811CMG | Non Drive Endshield |
| 8 | VPV826CMG | Switch Plate |
| 9 | VPV806CMG | Centrifugal Switch |
| 10 | VPV810CMG | Flanged Endshield |

