


POLIVAC WOMBAT VACUUM CLEANER



SCAN ME



Operations Manual & Trouble Shooting Guide

How to Operate a Polivac Wombat Vacuum Cleaner




Please find the following correct procedure for the operation of the Polivac Wombat

1. Plug the cable into a suitable 240 volts earthed power point. Always unwind the cable completely before commencing vacuuming.
2. Always ensure the dust bag is empty before commencing vacuuming
3. Make sure that the power cable is in good condition. Ensure that it doesn't get damaged around sharp objects or in door jams
4. Never operate the Polivac Wombat if the power cable is damaged in any way.
5. Attach the extension wand to the pistol grip and fit the floor tool or any of the other vacuuming accessories.
6. Dust bag. Open the lid and ensure that the cloth dust bag is correctly located and the flexible ring provides a proper seal when the lid is closed for optimum filtration and maximum hygiene. (Use a paper dust bag in addition to the standard cloth dust bag. To fit the paper dust bag, insert it into the cloth dust bag making sure that the cardboard disk is centred on the flexible-sealing ring. When you replace the lid, the short nozzle in the centre of the lid will be forced into the central hole of the cardboard disk of the paper dust bag thus providing a tight seal.)
7. Ensure that the lid clips are securely fastened.
8. Power Switch - The power switch is located on the rear base of the Polivac wombat. Switch it on, and you are ready to go.
9. If you are using an optional Power Head, attach it to the extension wand instead of the standard floor tool, and insert the plug the Power Head cable into the power outlet socket at the top of the front handle grip.
10. Never vacuum water or liquids.
11. Empty the dust bag when you have finished vacuuming.
12. Always wind the cord from the machine end first.

Barrel Vacuum Cleaner - Wombat

Diagram and Parts List



Barrel Vacuum Cleaner - Wombat

Parts List

No	Code	Description
1	PW004	Lid
2	PW003	Body
3	VVA218	Seal Lid
4	PW001	Inner Bag
5	PW005	Bag Ring
6	PW002	Outer Bag
7	VVA213	Castor
8	VVA211	Vac Cover Disc
9	PW007	Axle
10	AAG236	Flat Washer
11	GAS041	Spring Washer
12	PW100	Bolt
13	AAG365	Washer
14	PW008	Wheel
15	VVA223	Ratchet Cap
16	PW013/A	Fastener
17	PVT025	Flat Washer
18	PPR098	4 MM x 16 MM Screw
19	PPR095	4 mm Nyloc Nut
20	PW011	Foam Filter
21	PW016	Vac Screen
22	VVA228	Seal Motor
23	VVA235	Vac Motor
24	PW010	Gasket 1.5mm Elephantide
25	VVA230A	Rubber Bush
26	PW006	Back Plate

Barrel Vacuum Cleaner - Wombat

Parts List

No	Code	Description
27	PW014	Foam Filter
28	VPV191R	Rocker Switch
31	VPV193	Nylon Screw
32	PPR090	Bolt
35	VVA019	Clamp
36	VPV194	Nut
37	ECG157	Lead Protector
38	VPV474	Main Lead
39	GG5053	Selt tap Screw
41	BV8004	O Ring
42	BV8003	Strain Relief Kit
43	VVA402	Hose Assy
44	BOR0002	Wands X 2
45	BV8006	Floor Tool
46	VVA905	Sticker
47	BOR0004	Round Brush
48	PW098	6 MM X 25 MM Screw
49	AAB608	Screw
50	BOR0005	Crevice nozzle Black
51	PW014A	Foam Filter
52	PW017	Lead Holder

WARRANTY POLICY

1. When a warranty repair is requested, the purchaser must first contact any of Polivac's authorized Service Centres with proof of purchase and details of the alleged defect. In most instances, the request for warranty brought to the attention of our Service Centres or Agents is handled in a prompt routine manner with no question as to its validity. However, some requests for warranty are not justified. In these cases, product owners will be made aware that the premature failure of their product was the result of a cause not covered by Warranty.
2. The Polivac warranty covers only DEFECTIVE MATERIAL and/or DEFECTIVE WORKMANSHIP. It does not cover labour.
3. Polivac products are warranted for twelve (12) months from date of purchase by the original purchaser against faulty workmanship or material. The warranty covers only the replacement, repair or adjustment of any part which in the opinion of Polivac fails because of a fault in materials or workmanship:
 - a) drive motors and gearbox assemblies on electrical products carry a two (2) years warranty
 - b) bodies of carpet extraction products and vacuum cleaners carry a three (3) years conditional warranty.
 - c) battery warranty of twelve (12) months is as provided by the manufacturer. Terms available on request.
4. Where the product has been rented out by a Hire or similar company, the warranty period is reduced to three (3) months.
5. This warranty does not cover service calls, travelling time or consumable parts - e.g. drive belts, chains, flexible skirts or hoses, dust bags, mains leads, brushes, buffers, buffer strips, sanding discs, light bulbs, nozzles, filters, pressure pumps, piston seals, diaphragms, squeegees and like items.
6. In the case of proprietary components used by the manufacturer in the product, such as engines, electrical motors, chargers and the like, Polivac will pass on any warranty provided by the manufacture of such items.
7. Accidental damage, abuse, misuse or neglect of the product is not covered by warranty.
8. Fair wear and tear and where the product has been used other than for the purpose for which it was designed is not covered by warranty.
9. Use of non-approved chemicals and detergents in the product will void the warranty.
10. Products that have been modified are not covered by warranty.
11. Products that have not been serviced at their recommended intervals by an authorised Polivac Service Centre or Agent are not covered by warranty
12. Damage to, or failure of, the product which has resulted from low or high voltage, the use of an incorrectly sized extension lead, or a coiled electrical extension lead is not covered by warranty.
13. Repairs carried out on the product by any person other than an authorized Polivac repairer will void the warranty.
14. All freight charges to and from the manufacturer, agent or service centre will be the responsibility of the distributor.
15. A charge for traveling time and labour will be applicable for on-site warranty service.
16. Polivac reserves the right to replace defective parts of the product with parts or components of similar quality, grade and composition where an identical part or component is not available. Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired.

POLIVAC WARRANTY IS SUBJECT TO THE LAWS AND REGULATIONS OF THE INDIVIDUAL STATES AND COMMONWEALTH TERRITORIES OF AUSTRALIA. THIS WARRANTY IS NOT TRANSFERRABLE.

