

How to Operate a Gas 20" Propane Gas Burnisher GASS20



Please find the following correct procedure for the operation for the Polivac Gas 20" propane Burnisher.

1. Check engine oil level and condition. Ensure oil is viscous and that the correct level is present. Make sure that all daily maintenance procedures stated on the handle are carried out.
2. Fill the gas cylinder. (Gas cylinder filling should only be carried out by persons trained in propane gas bottle filling.)
3. Fit and secure the gas cylinder hose.
4. Open gas cylinder valve.
5. Set throttle to the start position.
6. Tilt the machine back to allow the pads to be off the floor.
7. Engage the starter button (A black button located at the back left hand side of the base)) until the machine begins operation. Each engagement should take no longer than 4-5 seconds
8. Run the machine for 2 minutes to ensure it is warm and to allow the oil to permeate the motor.
9. Push the throttle to 3/4 position, gently place the pad on the floor and then push in a forward movement.
10. STOPPING THE ENGINE:
 1. Tilt machine back, ensure that the pad is off the floor.
 2. Turn gas off at the bottle.
 3. Set the throttle lever to the start position.
 4. Clean machine before storing away.