


C25 TS

Driver & Base Assembly




C25TS Parts List

Driver and Base Assembly

1	PC40B1	Brush Assembly
2	PPR002	Continental Trim
3	AAK838	Pop Rivet
4	GCA292	Cap-Wheel Retain
5		
6	VPA571	Wheel-Rubber Tyre
7	AAG470	Washer Flat
8	VPA355	Pin-Wheel Retain
9	VPV170	Axle-Wheel
10	VWA634	Bush-Nylon
12	VPV218	Retaining Pin-Axle
13	AAD061	Bolt
14	AAG385	Washer-Flat
15	VPV782	Spacer
16	VPA139	Torsion-Spring
17	VPA138	Lever-Ratchet
18	SLB043	Nut Ratchet Lever
19	VPA412	Quick release Adaptor
20	VFB115	Key-Gear Shaft
21	VPA116	Gear Shaft
22	AAA628	Screw-Coupling Retain
23	AAG236	Washer-Flat
24	AAF140	Nut-Selloc, Skirt
25	VPA424	Skirt-Powder Coated
26	AAA564	Screw-Gear Cover
27	VPA122	Tab Washer
28	VPA113	Gear Cover
29	VPV251	Gasket tape bady to skirt
30	VPA950	Handle retain pin
31	VPA954	Clip
33	AAG236	Washer-Flat
34	AAD041	Screw-Skirt retaining
35	VPV482CMG	Drive Motor (see attached)
36	VPA104	Oil Seal-Top
37	AAA564	Screw-Motor
38	AAG236	Washer-Shakeproof
39	VPA177	Body Base Plate
40	VPA121	Washer-Wavy
41	VPA570	Bearing-Top
42	VPA411	Drive Gear
43	VPA118	Oil Seal-Bottom
44	VPA114	Bearing-Bottom

VPA1000 TS Handle








VPA 1000 TS Handle Parts List

1	AAE271	Hex Nut
2	AAG150	Washer
3	AAM702	Earth Terminal
4	VVA017	Earth Tag
5	AAB609	Self Tapper
6	AAG150	Washer
7 & 8	BV8003	Strain Relief & Ring
9	ECG157	Lead Protector
10	VPV475	Mains Lead Assy (15m)
11	AAD041	Bolt
12	AAF140	Stelloc Nut
13	VPA618	Stem Lead Assy
14	VPA767	Fork
15	VPA231	Tounge Assy
16	AAF140	Stelloc Nut
17	AAD039	Bolt
18	AAJ490	Star Washer
19	AAF140	Stelloc Nut
20	VPA841	Grommet
21	VPA765	Lead Hook
22	VPA819	Spacer
23	VPA824	Handle Stem & Switch Plate Assy
24	VPV555	Handgrip Set of 2
26	VPA926	Sleeve Insulation
27	ZDR078	Neon Indicator
28	VPA639	Cap
29	VPA828	Insulation
30	VPA622	Clamp
31	AAG150	Star Washer
32	AAE271	Nut
33	VPA632	Actuator
34	VPA689	Tensioner
35	OCX256	Spring
36	VPV491	Safety Button
37	VPA838	Trigger
38	VPV490	Cover Plate
39	AAJ003	Star Washer
40	AAE232	Acorn Nut
41	AAE200	Nut
42	VPV260	Flag Insulation
43	AAM701	Flag Receptacle
44	AAH229	Fibre Washer
45	VPA626	Blue Wire
46	VPA628	Brown Wire
47	VVA019	Clamp
48	AAM601	Terminal Block
49	VVA171	Screw
50	VPA631	Cherry Switch
51	AAE271	Nut
52	AAJ150	Star Washer
53	VPA622	Clamp
54	AAE297	Spacer
58	AAJ451	Star Washer
59	VVA224	2 Speed Switch
60	VPA618	Stem Lead
61	VLB120	3Pin Plug Rnd Pin

C25TS VPV 482 CMG

- | | | |
|----|-----------|------------------------------|
| 1 | VPV818CMG | Capacitor Box Cover |
| 2a | VPV800CMG | Start Capacitor |
| 2b | VPV800CMG | Run Capacitor* |
| | | (*only start capacitor used) |
| 3 | VPV817CMG | Capacitor Box Base |
| 4 | VPV807CMG | Manual Reset |
| 5 | VPV813CMG | Cowl |
| 6 | VPV812CMG | Cooling Fan |
| 6a | VPV819CMG | Clip on cooling fan |
| 7 | VPV811CMG | Non Drive Endshield |
| 8 | VPV805CMG | Switch Contact Plate |
| 9 | VPV806CMG | Centrifugal Switch |
| 10 | VPV810CMG | Flanged Endshield |
| 11 | VLB119 | 3 Pin Plug |



11